



Hazards	toxins
Tools/Equipment	brushers, rollers, fans, hoses, mixing drill and paddle, 6 mm poly zipper to seal area
Employee Group(s)	Facilities Management - Carpentry

Required PPE:



Safety Shoes



Eye Protection



Gloves



Protective Suit



Respirator

SAFE WORK PRACTICES

- Do not perform the procedure or operate the equipment until you have been appropriately trained and authorized to do so by your supervisor.
- Inspect required personal protective equipment (PPE) and replace if required.
- Prevent all contact with skin and eyes.
- Review safety data sheets prior to use and have available.

PROCEDURE

1. Install signage.
2. Advise Security about project.
3. Two-person job at all times.
4. Make sure flooring is clean and dry.
5. Set up temporary ventilation.
6. Turn off or cover main ventilation in the area.
7. Mix correct amounts of compound and resin – always read instructions.
8. Check application instructions.
9. After job is complete, dispose of rollers, brushes and suits.
10. Wash yourself with soap and water.
11. Barricade area until fumes dissipate, and epoxy is dry.

NOTE: All PPE, tools and equipment shall be used in accordance with provincial OH&S legislation, manufacturer's specifications, applicable standards and codes of practice.